

INTERCOM SYSTEM



The intercom panel at the front door of each building may vary slightly so if in doubt, check with the concierge.

Visitors should be able to buzz your apartment from the main door by pressing the number of your apartment and the CALL button; then you can have a two way conversation using the panel as illustrated above – you can open the main door if you wish to allow entry. Using this panel, you can also contact the concierge who will call you back via the intercom. This may not happen immediately as the concierge may be away from the reception desk attending to other duties. Your call, however, will be stored and dealt with when the member of staff returns.

There is no intercom between your apartment and the back door of the building or the pedestrian gate.

Some panels switch off automatically, on others you have to press the bottom button again. (You may hear 10 beeps before the unit switches off – this appears to be normal!)

This information has been produced by gem-uk-properties in good faith to assist our tenants as there is no official manual for this panel.